

EDGY MODS

Ram 2500 & 3500 Rear Raise Instructions

Make sure the key is out of the ignition and no power is on.

Spray a little WD40 or similar lubricant on the factory Link ends before removal.

1. Jack up the rear and locate the ride height sensor arms. They are connected to the end of the differential close to the brakes.
2. Simply twist and pull the factory Link off starting from the differential side.
3. Set new Adjustable Links to equal lengths. **Lengthening the Link from the factory length will raise the vehicle.** Each 5mm longer than stock will raise approx. $\frac{3}{4}$ - 1 inch.
4. Install with long end up.

Start the vehicle, move it forward and back to get the suspension active to the new settings. If you are not happy with the height you can easily re-adjust each Link. Just remove 1 side and give it a few turns. Usually 2 turns is about a $\frac{1}{4}$ inch in height.

Be a part of Edgy Mods. Go to the Gallery section and add your pictures.

Thank you for the purchase. If you have any questions please don't hesitate to ask anytime via phone or Email.

John Vranic

www.edgymods.com

604-780-7734