

EDGY MODS

Dodge Ram 2019 – 2021 Lower Instructions

Put the vehicle to the normal driving level. Make sure the key is out of the ignition and no power is on. Spray a little WD40 or similar lubricant on the factory Link ends before removal.

Front:

1. Look straight inside the wheel well and you will see the factory ride height sensor Link.
2. Simply twist and pull the factory Link off starting from the Control Arm side.
3. **Lengthening** the Link from the factory length will lower the vehicle. Each 5mm variance from stock will adjust the vehicle approx $\frac{3}{4}$ - 1".
4. Install with long end up.

Rear:

1. The rear Link is connected right in front of the rear tires.
2. Remove the Link the same way as the front.
3. **Shortening** the Link from the factory length will lower the vehicle. Same variance as the front.
4. Install with long end up.

Start the vehicle, raise it up and down and move it forward and back to get the suspension active to the new settings. If you are not happy with the height you can easily re-adjust each Link. Just remove 1 side of the Link and give it a few turns. Usually 2 turns is about a $\frac{1}{4}$ inch in height

Depending how low you make the vehicle a wheel alignment may be required to reduce tire wear.

Be a part of Edgy Mods. Go to the Gallery section and add your pictures.

Thank you for the purchase. If you have any questions please don't hesitate to ask anytime via phone or Email.

John Vranic

www.edgymods.com

604-780-7734