

EDGY MODS

BMW X5, X6 & 7 Series Rear Links Installation

Make sure the key is out of the ignition and no power is on.

Spray a little WD40 or similar lubricant on the factory Link ends before removal.

1. Jack up the rear and locate the stock ride height sensor Links. They are connected to the lower control arms.
2. Remove it by sliding a 10mm wrench over the Link and twisting it off.
3. Set new Adjustable Links to equal lengths. **Shortening the Link from the factory length will lower the vehicle.** Each 5mm shorter than stock will lower approx. $\frac{3}{4}$ - 1 inch.
4. Install with long end up.

Start the vehicle, move it forward and back to get the suspension active to the new settings. If you are not happy with the height you can easily re-adjust each Link to lower more or less. Just remove 1 side of the Link and give it a few turns. Usually 2 turns is about a $\frac{1}{4}$ inch in height

Depending how low you make the vehicle a wheel alignment may be required to reduce tire wear.

Be a part of Edgy Mods. Go to the Gallery section and add your pictures.

Thank you for the purchase. If you have any questions please don't hesitate to ask via phone or Email.

John Vranic

www.edgymods.com

604-780-7734



Rear Stock Link removal



Rear Adjustable Link Installed