

## EDGY MODS

### CLS63 2011 – 2017 & E63 2010 - 2016 Class Rear Instructions

**Make sure the key is out of the ignition and no power is on.**

**Spray a little WD40 or similar lubricant on the factory Link ends before removal.**

1. Jack up the rear and locate the stock ride height sensor Links. They're connected to the upper control arms.
2. Remove it by sliding an adjustable wrench over the arm and twisting it the same way. A 9mm wrench will also work.
3. **Shortening the Link from the factory length will lower the vehicle.** Each 5mm shorter than stock will lower approx.  $\frac{3}{4}$  - 1 inch. Set the new Adjustable Links so they are equal in length.
4. Install with long end up.

Start the vehicle, raise it up and down and move it forward and back to get the suspension active to the new settings. If you are not happy with the height you can easily re-adjust each Link. Just remove

1 side and give it a few turns. Usually 2 turns is about a  $\frac{1}{4}$  inch in height.

Depending how low you make the vehicle a wheel alignment may be required to reduce tire wear.

Be a part of Edgy Mods. Go to the Gallery section and add your pictures.

Thank you for the purchase. If you have any questions please don't hesitate to ask any time via phone or Email.

John Vranic

[www.edgymods.com](http://www.edgymods.com)

604-780-7734



Rear Stock Link



Rear Adjustable Link