

EDGY MODS

Ram 2500 & 3500 Rear Lowering Instructions

Make sure no power is on.

Spray a little WD40 or similar lubricant on the factory Link ends before removal.

1. Locate the ride height sensor arms. They are connected to the end of the differential close to the brakes and center of the Leaf Spring.
2. Pop the factory Link off starting from the Leaf Spring side using a flat head screwdriver. Once 1 side is off the other comes off easily by bending it backwards. Still be gentle enough to not break the sensor arm.
3. **Shortening the Link from the factory length will lower the vehicle and measure eye to eye.**
Each 10mm shorter than stock will lower approx. $\frac{3}{4}$ - 1 inch. Set the new Adjustable Links so they are equal in length.
4. Install with long end up.

Start the vehicle, move it forward and back to get the suspension active to the new settings. If you are not happy with the height you can easily re-adjust each Link. Just remove 1 side and give it a few turns. Usually, 5 turns is about a $\frac{1}{4}$ inch in height.

Thank you for the purchase. If you have any questions, please don't hesitate to ask anytime via phone or Email.

John Vranic

www.edgymods.com

604-780-7734



Rear Adjustable Link



Adjustable Link Installed