

EDGY MODS

Jaguar I-Pace Instructions

Make sure that no power is on.

Spray WD40 or similar lubricant on the factory Link ends before removal and for easy installation of Adjustable Links.

Front:

1. Jack up each corner and locate the stock ride height sensor Link. They're straight inside the wheel well right above the tire.
2. Pull the stock Links off. Start off on the control arm side and then the sensor.
3. **Lengthening the Link from the factory length will lower the vehicle.** Each 5mm longer than stock will lower approx. $\frac{3}{4}$ - 1 inch. Set the new Adjustable Links so that they are equal in length.
4. Install Adjustable Linkage with the long end up.

Rear:

1. While you have the front corner jacked up reach in front of the rear tire to locate the factory Links.
2. Use the same method as front to remove them.
3. **Shortening the Link from the factory length will lower the vehicle.** Each 5mm Shorter than stock will lower approx. $\frac{3}{4}$ - 1 inch. Set the new Adjustable Links so that they are equal in length.
4. Install Adjustable Link with the long end up.

Start the vehicle, raise it up and down and move it forward and back to get the suspension active to the new settings. If you are not happy with the height you can easily re-adjust each Link to lower more or less. Simply pop off one side of the Link and give it a few turns. Usually, 2 turns is about a $\frac{1}{4}$ " in height.

Depending how low you make the vehicle a wheel alignment may be required to reduce tire wear.

Always looking to add more photos to our gallery. Submit yours by email or text.

Thank you for your purchase. If you have any questions, please don't hesitate to ask via phone or Email.

John Vranic

www.edgymods.com

604-780-7734