

EDGY MODS

BMW 7 Series 2023 – 2025 Instructions

Make sure no power is on.

Spray a little WD40 or similar lubricant on the factory Link ends before removal.

Front:

1. Jack up each corner and locate the stock ride height sensor Links. They're straight inside the wheel well right above the tire.
2. **The stock Links are attached to plastic ball studs and are very easy to break. Remove the complete assembly. Remove the top 10mm nut and then unclip the ball stud housing attached to the sensor arm. Once all removed carefully bend backwards each end to pop out the ball studs. You may even want to put a slice at the top of the plastic link to pop off easier.**
3. Re attach both ends to the vehicle.
4. **Lengthening the Link from the factory length will lower the vehicle.** Each 5mm longer than stock will lower approx. $\frac{3}{4}$ - 1 inch. Set the new Adjustable Links so they are equal in length.
5. Install Adjustable Links with long end up.

Rear:

1. Jack up the rear and locate the rear ride height sensor Links. They're connected to the lower control arms.
2. **Same as front, the stock Links are attached to plastic ball studs and are very easy to break. Remove the complete assembly. First unclip the ball stud housing that's attached to the sensor arm, then remove the bottom 10mm bolt. Once all removed carefully bend backwards each end to pop out the ball studs. Again, you may even want to put a slice at the top of the plastic link to pop off easier.**
3. Re attach both ends to the vehicle.
4. **Shortening the Link from the factory length will lower the vehicle.** Each 5mm shorter than stock will lower approx. $\frac{3}{4}$ - 1 inch. Set the new Adjustable Links so they are equal in length.
5. Install with long end up.

Start the vehicle, raise it up and down and move it forward and back to get the suspension active to the new settings. If you are not happy with the height you can easily re-adjust each Link. Just remove 1 side and give it a few turns. Usually, 2 turns is about a $\frac{1}{4}$ inch in height.

- Depending how low you make the vehicle a wheel alignment may be required to reduce tire wear.
- Always looking to add more photos to our gallery. Submit yours by email or text.

Thank you for the purchase. If you have any questions, please don't hesitate to ask any time via phone or Email.

John Vranic

www.edgymods.com

604-780-7734



Front Stock Link



Bracket Removed



Adjustable Link Installed



Front Stock Link



Bracket Removed



Adjustable Link Installed