

# **EDGY MODS**

## **Denali, Tahoe, Suburban & Yukon Lift Instructions**

Before you begin the install disable the Auto Entry / Exit feature then make sure the power is off.

### **Front:**

1. Jack up the front corner and locate the stock ride height sensor Link. It's straight inside the wheel well right above the tire. You can do the rear at the same time without repositioning the jack.
2. To remove the factory Link pop off the Control Arm side first using a flat head screwdriver.  
**To do the sensor side you must push out the little Pin and then slide it off the ball stud.**
3. **Shortening the Link from the factory length will lift the vehicle.** Each 5mm shorter than stock will lift approx.  $\frac{1}{2}$  -  $\frac{3}{4}$  inch. Set the new Adjustable Links so they are equal in length.
4. Install Adjustable Links with the long end up. Blue end to the Control Arm and Black end to Sensor.

### **Rear:**

1. While you have the front corner jacked up, do the rear. They are located right in front of the rear tire.
2. Remove the same way as the front. Control Arm side first and then be sure to remove the pin.
3. **Lengthening the Link from the factory length will lift the vehicle.** Each 5mm longer than stock will lift approx.  $\frac{1}{2}$  -  $\frac{3}{4}$  inch. Set the new Adjustable Links to equal lengths.
4. Install with long end up. Black end to the Sensor and Blue end to Control Arm.

Start the vehicle, raise it up and down and move it forward and back to get the suspension active to the new settings. If you are not happy with the height you can easily re-adjust each Link. Just remove 1 side and give it a few turns. Usually, 3 turns is about a  $\frac{1}{4}$  inch in height.

After you Lift the vehicle, it's not recommended to go to the highest setting.

Depending how high you make the vehicle a wheel alignment may be required to reduce tire wear.

Always looking to add more photos to our gallery. Submit yours by email or text.

Thank you for the purchase! If you have any questions, please don't hesitate to ask any time via phone, text or Email.

John Vranic  
[www.edgymods.com](http://www.edgymods.com)  
604-780-7734



Front Stock Link



Adjustable Link Installed



Rear Stock Link



Adjustable Link Installed