

EDGY MODS

Mercedes Benz 2021 - 2025 S (W223) Class

Make sure no power is on.

Spray a little WD40 or similar lubricant on the factory Link ends before removal.

Front:

1. Jack up each corner and locate the stock ride height sensor Link. It's straight inside the wheel well above the tire, connected to the upper Control Arm.
2. To remove the stock Link start by removing the bracket that's attached to the Control Arm. Then bend the Link backwards against the Sensor Arm and carefully pop it off. Once off bend the bracket from the other side of the Link. Re-attach bracket to Control Arm
3. **Lengthening the Link from the factory length will lower the vehicle.** Each 5mm longer than stock will lower approx. $\frac{3}{4}$ - 1 inch. Set the new Adjustable Links so they are equal in length.
4. Install with long end up.

Rear:

1. Jack up the rear and locate the stock ride height sensor Links. They are connected to the lower Control Arms.
2. Remove it the same way as front. Remove the bracket and pop off Sensor Arm.
3. **Lengthening the Link from the factory length will lower the vehicle.** Each 5mm longer than stock will lower approx. $\frac{3}{4}$ - 1 inch. Set the new Adjustable Links so they are equal in length.
4. Install with long end up.

Start the vehicle, raise it up and down and move it forward and back to get the suspension active to the new settings. If you are not happy with the height you can easily re-adjust each Link. Just remove 1 side and give it a few turns. Usually, 2 turns is about a $\frac{1}{4}$ inch in height.

Depending how low you make the vehicle a wheel alignment may be required to reduce tire wear.

Always looking to add more photos to our gallery. Submit yours by email or text.

Thank you for the purchase. If you have any questions, please don't hesitate to ask anytime via phone or Email.

John Vranic
www.edgymods.com
604-780-7734



Front Stock Link



Remove bracket



Adjustable Link Installed



Rear Stock Link



Remove bracket



Adjustable Link Installed