

EDGY MODS

Chevy Silverado, GMC Denali & Sierra EV Lower Instructions

Make sure no power is on.

Spray a little WD40 or similar lubricant on the factory Link ends before removal.

Front:

1. Jack up the front corner and locate the stock ride height sensor Link. It's straight inside the wheel well right above the tire.
2. To remove the factory Link pop off the Control Arm side first using a flat head screwdriver. Once 1 side is off the other comes off easily by bending it backwards. Still be gentle enough to not break the sensor arm.
3. **Lengthening the Link from the factory length will lower the vehicle.**
Each 5mm longer than stock will lower approx. $\frac{1}{2}$ - $\frac{3}{4}$ inch. Set the new Adjustable Links so they are equal in length.
4. Install Adjustable Links with the long end up. Blue end to the Control Arm and Black end to Sensor.

Rear:

1. Jack up the rear and remove the wheel. It's very tight to remove the link from underneath but you can adjust it once installed. They are connected to the upper Control Arms and are very short.
2. Remove the same way as front.
3. **Lengthening the Link from the factory length will lower the vehicle.** Each 5mm longer than stock will lower approx. $\frac{1}{2}$ - $\frac{3}{4}$ inch. Set the new Adjustable Links so they are equal in length.
4. Install Adjustable Links with the long end up. Blue end to the Control Arm and Black end to Sensor.

Start the vehicle, raise it up and down and move it forward and back to get the suspension active to the new settings. If you are not happy with the height you can easily re-adjust each Link. Just remove 1 side and give it a few turns. Usually, 3 turns is about a $\frac{1}{4}$ inch in height.

Depending how high you make the vehicle a wheel alignment may be required to reduce tire wear.

Always looking to add more photos to our gallery. Submit yours by email or text.

Thank you for the purchase. If you have any questions, please don't hesitate to ask any time via phone, text or Email.

John Vranic

www.edgymods.com

305-240-9629



Front Stock Link



Front Adjustable Link



Rear Stock Link



Rear Adjustable Link